



SUPER CODE INSTRUCTIONS (SafeLogic C10 D-Drive)

Document No.: LM-200401

Version No.: V1.01 SUPER

ALWAYS CHANGE THE MANUFACTURER'S DEFAULT SUPER CODE BEFORE THE PRODUCT LEAVES YOUR COMPANY. THE MANUFACTURER WILL NOT BE RESPONSIBLE FOR ANY DISPUTE CAUSED BY UNCHANGED MANUFACTURER'S DEFAULT SUPER CODE .

Super Code Overview

1. Super Code Features
 - a. Can be used to open the safe lock
 - b. Can be used to manage Manager's Code
 - c. Can be used to perform below programming features
 - Enable Dual Mode
 - Disable Dual Mode
 - Set Time Delay
 - Set TDO User
 - Audit (Optional USB Adaptor & Software Needed)
 - d. Manufacturer's default Super Code: 1-1-1-1-1-1
2. System Connection and Test
 - a. Connect Entrypad to the Lock body using the provided 4-wire lock cable.
 - b. Install a 9v alkaline battery in EntryPad
 - c. Open the lock using the Super Code 1-1-1-1-1-1
3. Change the Super Code (ID00)
 - a. Enter "0" six times. One beep sounds.
 - b. Enter the old code. One beep sounds.
 - c. Enter a new six (6) digit code once. One beep sounds.
 - d. Re-enter the new six (6) digit code. One beep sounds, indicating that the codes entered in step c and d are the same and the code has been changed successfully.

- e. If three beeps sound, the code changing process failed. The existing code is still valid. Repeat steps a through d.

Note:

- User Code can't be 000000 or 999999.
4. Dual Mode (Open lock with Manager Code plus one User Code.)
 - a. Enter Super Code and hold down last digit of code until two beeps sound.
 - b. Press button "8" to set lock to Dual User Mode.
 5. Single Mode (Open lock with single user code.)
 - a. Enter Super Code and hold down last digit of code until two beeps sound.
 - b. Press button "0" to set lock to Single User Mode.
 6. Set Time Delay and Time Window
 - Time Delay: A time period of waiting for the lock to open. The maximum Time Delay is forty (40) minutes
 - a. Time Window: A time period for entering the code (s) to open lock after Time Delay. The maximum Time Window is twenty (20) minutes.
 - b. Enter Super Code and hold down last digit of code until two beeps sound.
 - c. Press button "9". One beep sounds.
 - d. Enter a six (6) digit number in the range of 001001 - 040020. One beep sounds.
 - The first 3 digits are for the Time Delay.
 - The second 3 digits are for the Time Window.
 - For example, enter 015003, to set below;
 - A fifteen (15) minute Time Delay and a three (3) minute Time Window.
 7. Cancel Time Delay and Time Window
 - a. Enter Super Code and hold down last digit of code until two beeps sound.
 - b. Press button "9". One beep sounds.
 - c. Enter a six (6) digit number 000000. One beep sounds.
 - The first 3 digits (000) are to cancel the Time Delay.
 - The second 3 digits (000) are to cancel the Time Window.

8. Set TDO User (TDO User opens with Time Delay Override)
 - a. Enter Super Code and hold down last digit of code until two beeps sound.
 - b. Press button "4". One beep sounds.
 - c. Enter the user ID (2~9). One beep sounds, indicating that the setting is successful.

9. Delete TDO User (No User can open with Time Delay Override)
 - a. Enter Super Code and hold down last digit of code until two beeps sound.
 - b. Press button "4". One beep sounds.
 - c. Press button "0". One beep sounds.

10. Audit (Optional USB Adaptor & Software Needed.)
 - a. Connect the USB Adaptor to the entrypad.
 - b. Enter Super Code and hold down last digit of code until two beeps sound.
 - c. Press button "7". One beep sounds, followed by one more beep indicating that the extracting is successful.

Note:

 - Use one USB Adaptor to extract the audit from one lock only.
 - The USB Adaptor saves only one lock's audit.

Follow the "Audit Kit" software instructions to export the audit.