

TURNBULL GUN CABINETS

The Securikey Turnbull Gun Cabinets are designed to be secured to wall and/or floor.

Location:

The decision on where to site and install your cabinet should take into consideration its concealment and make possible attack methods as difficult as possible.

- The corner of a room is the ideal location for a gun safe, naturally hindering potential intruders by concealing at least two sides of the cabinet and minimising the opportunity for leverage of the door, locks or the casing itself.
- Where feasible site the cabinet so as to restrict access to the bottom, sides and top.
- Any obstacles such as skirting board should be removed so there is no gap between the back of the cabinet and the wall.
- Select a good sound, level wall and/or floor to which to install your safe, ensuring that no services will be interfered with.
- Of course, the security of the safe is important but you should also think about the practicalities of using it:

Anchoring procedure:

- The Cabinet must be anchored to the floor or to the wall (preferably both) and there are 10mm fixing holes provided for this purpose in the base and back.. The type of fixing bolt to be used depends on the structure to which the safe is to be anchored.
- Place the Cabinet in the desired location and check that full access will be possible.
- Using the Cabinet as a template, mark the fixing position on the surface to be drilled.
- Using a concrete bit, drill a hole to a depth of 70mm or as advised with the fixings purchased.
- Remove the dust from the hole using a vacuum cleaner and repeat for the other fixings holes to be used.

The 'Key' locking safe version is equipped with a high-security lock with 2 double-bitted keys.

For further assistance please contact your local stockist or alternatively contact:
Securikey Limited, PO Box 18, Aldershot, Hampshire GU12 4SL
Telephone: 01252 311888/ enquiries@securikey