


Master Lock® 1500i ONE Combination Padlock

Operating Instructions


Each lock is supplied with a 4 operation code consisting of ←↑↓→ movements.

The combination of your lock is shown on the instructions included and will look similar to these **examples**:



Opening the Lock for the first time



1. Squeeze the shackle (A) towards the lock body and release to 'clear' it each time before opening the lock.
2. 'Dial' your combination by sliding the button (B) to each position in the combination pattern (up, down, left, right). Be sure to slide the button all the way in each direction, letting the button spring back to the centre before moving to the next position.
3. Pull up on the shackle to open the lock.
4. To close the lock, put the shackle back to its initial position and,
5. squeeze it toward the lock body to scramble the combination.



IMPORTANT: ALWAYS SQUEEZE THE SHACKLE EACH TIME YOU OPEN THE LOCK

“How to change the combination

1. Dial the combination and place the lock in the open position.
2. On the back of the lock, use a pointed object to slide the reset lever into the ‘up’ position (towards the “R”)
3. Squeeze the shackle to close the lock.
4. Pull up on the shackle to open the lock.
5. Enter your new combination.
6. **Slide the reset lever back to the ‘down’ position.**
7. Squeeze the shackle closed and release. The lock will now open with your new combination.
8. Do not forget to save your combination to a safe place.



Note: you can set your combination to any pattern or length. For extra security, it is best to create a longer combination using several of the up, down, left, right positions. Write the pattern down, once you change it.

To reset the combination again, just repeat steps 1-8