

Institutional Mirrors

Polycarbonate Anti-Vandal Vanity Mirror




7mm Counter-bore Holes



Button Head Torx Security Masonry Screw
Size: 1/4" x 1 3/4" (6.35mm x 44.45mm)
Driver Size: #27 Torx Security 1/4" (6.35mm) Hex Bit
Drill Dia: 3/16" (4.76mm)

Torx Screw Installation Guide:

- It is recommended to use a 3/16" (4.76mm) Straight Shank Tanged Bit to drill the hole.
- The hole must be at least 2" or 50mm overall depth and free of any debris.
- By using the #27, 1/4" (6.35mm) Hex Bit the special Hi-Lo thread literally taps into masonry materials.
- The high, sharp thread with its notched cutting edge cuts deeply and easily.
- The alternating low thread provides stability for fast, accurate driving.
- Torx screws are suitable for use in concrete, brick, or hollow block. Make sure the surface is flat and do not over-tighten screws.



Polycarbonate Cleaning Instructions

Because polycarbonate is softer than glass clean with soap and water and then with a soft, lint free, damp cloth.

DO NOT USE:

- abrasives
- acids
- solvents such as petrol and laquer thinners

POLISH:

Use a non-abrasive polish, such as Johnson's Pledge for a clear bright reflection. Saturate a clean soft cloth with polish, then spray the mirror face with polish. Wipe the wetted cloth over the mirror surface. With a another clean dry cloth buff the mirror face until it is clear of polish.

GRAFFITI REMOVAL:

Any graffiti should be removed from the mirror face as soon as possible and preferably within 24 hours. To remove graffiti, use a non-abrasive substance such as De-Solv-it stain remover. Not all graffiti cleaning agents are suitable. Failure to use an approved cleaning agent may damage the mirror surface.